

# Mercedes Sprinter 2.0 OM654

SB23070062 // Options



RWD	With N63	TM/QP13-15-16		KC20050500	*Ref.N63 = 1111100500
			Automatic tensioner	KC23030566	
	TM/QP21		KC20060501		
	With N63 + Bracket	TM/QP13-15-16		KC22100555	
	Without N63	TM/QP13-15-16		KC20090510	
			Automatic tensioner	KC23030567	
	Without N63	TM/QP13-15-16		KC21080525	
FWD	With N63	TM/QP13-15-16		KC21110533	



**OLIVA TORRAS**  
MOUNT & DRIVE KITS